

ENGLISH PART	RUSSIAN PART
Operation ❶ ON/OFF: When the flashlight is off, single click the switch # to turn on the flashlight, click again to turn it off. The flashlight has memory function, will memorize default output selections, but not flash modes. ❷ Default output selections: When the flashlight is on, press and hold # switch to cycle through Eco-Low-Med-High, release to select your desired output. ❸ Instant Eco: When the flashlight is off, press and hold the # switch to activate Eco, not release to adjust the output, click to turn it off. ❹ Instant Turbo: When the flashlight is not High mode, double click the # switch to activate the highest mode, click to turn it off. ❺ Flash Modes: When the flashlight is off, double click on # switch to activate Strobe, double click again to activate SOS, click to exit the flash mode. ❻ Breathing Light: Triple click the # switch to turn on the breathing light, triple click again to turn it off. ❼ Lock/Unlock: When the flashlight is off, 4 times click on the # switch, the front lamp will blink 3 times to indicate locking status, then any operation on the switch will activate nothing except another 4 times click the # switch to unlock the flashlight and turn on Eco.	❶ ON/OFF: Нажмите на переключатель #, чтобы включить фонарь, нажмите еще раз, чтобы выключить его. Фонарь имеет функцию памяти, запоминает последний режим работы. ❷ Выбор сигнала по умолчанию: Когда фонарь включен, нажмите и удерживайте переключатель # для цикла Eco-Low-Med-High, отпустите, чтобы выбрать желаемый режим. ❸ Мгновенный режим Есо: Когда фонарь выключен, нажмите и удерживайте # переключатель, чтобы активировать режим Есо, не отпускайте, чтобы отрегулировать мощность, нажмите один раз, чтобы выключить. ❹ Мгновенный турбо: Когда фонарь не находится в режиме High, дважды нажмите на # переключатель, чтобы активировать самый яркий режим, нажмите, чтобы выключить. ❺ Режимы вспышки: Когда фонарь выключен, дважды нажмите на # переключатель, чтобы включить режим "Строб", дважды нажмите, чтобы включить режим SOS, нажмите, чтобы выйти из режима "Flash". ❻ Мерцающий свет: Трижды нажмите на # переключатель, чтобы включить подсветку, еще раз трижды нажмите, чтобы выключить . ❼ Блокировка/разблокировка: Когда фонарь выключен, 4 раза нажмите на # переключатель, светодиод мигнет 3 раза, чтобы показать состояние блокировки, 4-х кратное нажатие на # переключатель разблокирует фонарь и включит Есо.