

ENGLISH PART	RUSSIAN PART
Operation: 1. Power on/off: press the rear switch to turn on the flashlight, press again to turn off the flashlight. 2. Gear position adjustment: In the on state, lightly touch the tail switch to switch the gear position (the gear position is set to energy saving - low brightness - medium brightness - high brightness, switching cycles, with gear memory). 3. SOS: In the on state, tap the switch twice quickly, the flashlight will enter SOS mode, tap the switch again, the flashlight will return to the lighting position.	Инструкция: 1. Включение/выключение питания: нажмите переключатель, чтобы включить фонарик, нажмите ещё раз, чтобы выключить фонарик. 2. Выбор режимов: во включенном состоянии слегка коснитесь переключателя, чтобы перебрать цикл: «энергосбережение-низкий-средний-высокий». 3. SOS: во включенном состоянии дважды слегка коснитесь переключателя - фонарь перейдет в режим SOS, снова коснитесь переключателя - и фонарик вернётся в положение освещения.